Task: Measure the orientation of the Benglebone blue and display it by setting the position of a servo motor.


Solution: In the file Hulonfij BBBlue. json we can see, that we can get the orientation of the Benglebone blue as a quaternion. We can look at a quaternion as a cotation around an axis: $q_0 = \cos\left(\frac{x}{2}\right)$ $q_1 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_2 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_3 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_4 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_5 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_6 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_7 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_8 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$ $q_8 = \sin\left(\frac{x}{2}\right) \cdot \cos\left(\beta_2\right)$

, with 1: rotation around the aris and PK17,2" angles between the 3 coordinate axes and the axis of rotation

With a single serve motor we can only display the rotation of the Beaglebone blue around one axis. Left go with the x-axis. The quaternion will then be $q_0 = cos(\frac{L}{L})$ $q_1 = sin(\frac{L}{L}) \approx \frac{L}{L}$, for small L $q_2 = q_3 = 0$

For small angles L, We can directly use que, multiply it by 2 and send this value to the serve motor.

We therefore get the following control system:



Since the IMM and the seros have slow update rates, it is sufficient to let those blocks run in a timedomaine with 100 ms.